


Applications of Elastic Behaviour of Materials

How the physical limits of solids shape the design of buildings, bridges, and mountains.



THE CORE PRINCIPLE

Engineering within the Elastic Limit


Every solid object deforms under force. The goal of structural engineering is to ensure that deforming forces never push a material past its yield point, preventing permanent, unsafe plastic deformation.

COMPRESSION




Withstanding compressive vertical loads from massive weight without fracturing or collapsing.

BENDING



Managing sagging and structural bending under moving traffic and wind shear.

TENSION



Calculating safe tensile loads to prevent metallic lifting ropes from snapping.

Rule of Thumb: Engineers calculate theoretical limits but typically apply a safety factor of 10x to account for dynamic, unpredictable real-world forces.

TENSION & YIELD STRENGTH

Calculating Safe Rope Thickness


To lift a heavy load (W) without permanent deformation, the stress applied to the rope must not exceed the material's yield strength (σ_y). For a crane lifting 10 tonnes (10^4 kg), mild steel requires a specific minimum cross-sectional area.

$$A \geq \frac{W}{\sigma_y}$$

$$A = (10^4 \text{ kg} \times 9.8 \text{ m/s}^2) / (300 \times 10^6 \text{ N/m}^2) = 3.3 \times 10^{-4} \text{ m}^2$$

Why Braided Ropes?

A single 3cm thick steel wire would be as rigid as a solid rod. Braiding multiple thin wires provides the necessary total area (A) while maintaining flexibility and strength.





You've Learned the Theory. Let's Test Them Now.

$$E=mc^2$$



Turn theory into marks with **unlimited MCQs, smart analysis, and focused revision.**

Practice Now



At prep.topall.app


Key Highlights

- » Free Study Material, Videos & Infographics
- » Push Your Limits with Level-Based Challenges
- » Climb the Leaderboard Among Fellow Aspirants
- » Practice Unlimited MCQs for NEET & JEE
- » Get Clear Explanations, Not Just Marks
- » Track Your Performance Smarter



The Mechanics of a Loaded Beam

When a beam spans a distance and supports a central load, it sags (depresses) by an amount δ . Minimizing this sag is crucial for structural stability.



$$\delta = \frac{Wl^3}{4bd^3Y}$$

[W = Load]

[l = Span length]

[b = Breadth]

[d = Depth]


[Y = Young's Modulus]

MATHEMATICAL INSIGHT

The Power of the Cubed Variable (d^3)

Looking at the denominator of the bending formula ($4bd^3Y$), how should we thicken a beam to make it stronger? The math reveals a clear winner.


Increasing Breadth (b)



$$\delta \propto 1/b$$

Linear relationship. Doubling the breadth reduces the sag by exactly a factor of 2.

Increasing Depth (d)



$$\delta \propto 1/d^3$$

Exponential relationship. Doubling the depth reduces the sag by a massive factor of 8.


For maximum strength with minimal material weight and cost, beams should be designed vertically deep, not horizontally wide.

THE PHYSICAL LIMITATION

The Danger of Deep, Thin Bars

If increasing depth (d) is mathematically optimal for preventing sag, why not make beams infinitely deep and paper-thin?


When a beam becomes too deep and thin, it loses lateral stability. Unless the downward load is perfectly centered at all times (impossible in a bridge with moving traffic), the beam will violently twist and bend sideways.



[! BUCKLING]

The Anatomy of the I-Beam


The I-section beam is the ultimate structural compromise, engineered specifically to solve sagging and buckling simultaneously.



Shape matters as much as material. The 'I' shape delivers maximum structural efficiency by directly exploiting the formulas of elasticity.

From Pillars to Mountain Peaks

Pillars - Distributing Load



Concentrated Stress

Distributed Stress

Distributing compressive load over a wider area (A) reduces stress (F/A), preventing structural failure at the base.

Mountains - The Geological Limit

Why are there no 20 km tall mountains on Earth?

The immense weight of a mountain creates shearing stress ($h\rho g$) at its base.

$$h\rho g = \text{Rock's Elastic Limit}$$

$$h = \frac{30 \times 10^7 \text{ N/m}^2}{3 \times 10^3 \text{ kg/m}^3 \times 10 \text{ m/s}^2} = 10 \text{ km}$$

If a mountain exceeds ~10 km, the **base stress surpasses typical rock's elastic limit**. The rock permanently deforms and flows like a viscous fluid. **Mount Everest is at Earth's physical ceiling.**



You've Learned the Theory.

Now Let's Test It.

Reading notes gets you knowledge.

Practicing MCQs gets you marks.

That's exactly what TopAll Pro is built for.

Try TopAll Pro Now

What TopAll Pro Does Differently

-  **Stuck? Snap it. Solve it. — Doubts AI**
Photo → step-by-step solution in seconds, 24/7
-  **Your AI Coach finds your blind spots**
Concept-level weakness detection — not just chapter-level
-  **4.5 Lakh+ questions. Never run out.**
13× more content than any other prep app in India
-  **Build your own test in 60 seconds**
Pick a chapter, set difficulty — AI does the rest instantly.
-  **AI Recommendation that helps you improve**
AI Recommendation Analysis your Tests and tell you where you need to improve.



Practice the moment you finish studying
Jump in while the concept is still fresh in your head

4.5L+
MCQs

1.5L+
Students

AI Powered
In-Depth Analysis